

## HOME INTERFACES ROUTING FIREWALL VPN SERVICES SYSTEM LOGOUT

	Link Supervision				
WAN Link Management Supervision Settings	be declared as down in case all trial reached.		ings on each WAN link to authoritative hosts. The link will her specify an emergency action if a certain downtime is  ANY = Pings are sent over all available WAN-links.  Select the interface over which the pings shall be sent  The host will be checked as soon as the connection is up. The host must be reachable on the Internet.  (optional)		
Ethernet Port Assignment VLAN Management IP Settings	Link: Mode:	also validate wh     only validate if lir			
Mobile SIMs Interfaces	Primary host: Secondary host:	8.8.8.8			
USB Serial	Ping timeout: Ping interval:	2000 milliseco 5 seconds	estab	The host will be checked after the connection establishment. Select this mode if the host only is reachable over a tunnel (OpenVPN/IPsec)	
Digital I/O	Retry interval (if ping failed):	3 seconds			
GNSS	Max. number of failed trials.	3			
How long the ping does take The worse the connection th timeout.		none restart link service reboot system after 10 minutes		ion shall be executed after 10 eing down	

Apply